

Pressure Drop vs. C-factor

1" Tri-Packs

