

Pressure Drop vs. C-factor

3.5" Tri-Packs

